



<sup>®</sup>  
**AF-3000**  
Compact AC Inverter  
Operating & Maintenance Manual



**THE  
AVAILABLE  
SOLUTION**



**DANGER**

Voltage is present on capacitors for five minutes after input circuit is open. Risk of electric shock and/or electrical energy-high current levels.

**WARNING**

Disconnect electrical supply before servicing the electrical system.

Do not change the wiring while power is applied to the circuit.

Do not check signals during operation.

**WARNING**


Refer to this manual for connection of circuits and the rating of auxiliary circuits.

Be sure to ground AF-3000 using the ground terminal G(E).

Never connect main circuit output terminals T1(U), T2(V), T3(W) to AC main circuit power supply.

**CAUTION**

Separate motor overcurrent, overload and overheating protection is required to be provided in accordance with CANADIAN ELECTRICAL CODE, PART I and NEC.



This instruction manual is composed of 2 sections: The first section describes handling, wiring, operation, maintenance/inspection, troubleshooting and specifications of the AF-3000 Digital Compact Inverter. The second outlines the digital operator performance, constants, operation, etc.

Before using the AF-3000, a thorough understanding of this manual is recommended for daily maintenance, inspection and troubleshooting.

In this manual, "constant (No. [ ])" indicates the item number of control constant set by digital operator.

### DANGER

Voltage is present on capacitors for five minutes after input circuit is open. Risk of electric shock and/or electrical energy-high current levels.

### WARNING

Disconnect electrical supply before servicing the electrical system.

Do not change the wiring while power is applied to the circuit.

Do not check signals during operation.

### WARNING

Refer to this manual for connection of circuits and the rating of auxiliary circuits.



Be sure to ground AF-3000 using the ground terminal G.

Connect the motor to output terminals T1, T2, T3. Connect an AC power supply to input terminals L1, L2, L3 (for 240 V single-phase series, connect only to L1 and L2).

### CAUTION

Separate motor overcurrent, overload and overheating protection is required to be provided in accordance with CANADIAN ELECTRICAL CODE, PART I and NEC.

	Page
1. AF-3000 INVERTER MAIN UNIT .....	1
1.1 PARTS NAMES OF AF-3000 .....	1
1.2 RECEIVING .....	2
1.2.1 Nameplate Data .....	2
1.2.2 Type Designation .....	3
1.3 INSTALLATION .....	4
1.3.1 Transportation .....	4
1.3.2 Mounting Space .....	4
1.3.3 Location .....	5
1.4 WIRING .....	6
1.4.1 Terminal Cover Mounting/Removing and Terminal Position .....	6
1.4.2 Standard Wiring Diagram .....	8
1.4.3 Main Circuit .....	10
1.4.4 Control Circuit .....	20
1.5 OPERATION .....	24
1.5.1 Pre-operation Check .....	24
1.5.2 Pre-operation Setting .....	25
1.5.3 Test Run Method .....	27
1.5.4 Inverter Status Display LEDs .....	29
1.5.5 Digital Operator Display .....	30
1.5.6 Check Points at Test Run .....	31
1.6 MAINTENANCE .....	32
1.6.1 Periodical Inspection .....	32
1.6.2 High Voltage Test .....	33
1.7 FAULT DISPLAY AND TROUBLESHOOTING .....	34
1.7.1 Checking of Causes .....	34
1.7.2 Alarm Display and Contents .....	38
1.7.3 Corrective Action for Motor Faults .....	40
1.8 SPECIFICATIONS .....	42
1.8.1 Specifications .....	42
1.8.2 Dimensions in inches (mm) .....	50
2. DIGITAL OPERATOR (OS-9) .....	51
2.1 DIGITAL OPERATOR MOUNTING/REMOVING .....	51
2.2 DESCRIPTION OF DIGITAL OPERATOR DISPLAY AND OPERATING SECTIONS .....	52
2.3 FUNCTION/CONSTANT SETTING .....	54
2.3.1 DRIVE Mode and PRGM (Program) Mode .....	54
2.3.2 Constant Reading and Setting .....	56
2.3.3 Precautions on Constant Setting .....	58
2.4 DIGITAL OPERATOR OPERATION EXAMPLE .....	60
2.5 CONSTANT INITIALIZATION AND WRITE-IN PROHIBIT .....	62
2.5.1 Constant Initialization (Operation to return to factory setting) .....	62
2.5.2 Constant Write-in Prohibit (Only constant reading possible) .....	63
2.6 CORRECTIVE FUNCTION .....	64
2.6.1 Adjustment of Frequency Setting Value, Output Frequency Bias (No. 23) and Gain (No. 22) .....	64



	Page
2.6.2 Calibration of Frequency Meter .....	66
2.7 MONITOR .....	68
2.7.1 Typical Monitor Contents and Display (DRIVE Mode) .....	68
2.7.2 Monitoring of Fault Contents .....	69
2.8 FUNCTION/CONSTANT LIST .....	70
2.8.1 First Functions (Constant Nos. 00 to 19) .....	70
2.8.2 Second Functions (Constant Nos. 20 to 31) .....	73
2.8.3 Third Functions (Constant Nos. 30 to 59) .....	75
2.9 DESCRIPTION OF FUNCTIONS AND CONSTANTS .....	79
• PASSWORD SETTING .....	79
• OPERATION MODE SELECTION .....	80
• 4-STEP SPEED CHANGE .....	82
• S-CURVE PATTERN SELECTION .....	83
• V/f CHARACTERISTIC SETTING .....	84
• JOG OPERATION .....	86
• ACCEL/DECEL TIME SETTING .....	87
• OUTPUT FREQUENCY CONTROL (GAIN/BIAS) .....	88
• ELECTRONIC THERMAL OVERLOAD PROTECTION .....	88
• MULTIFUNCTION ANALOG OUTPUT MONITOR SETTING .....	90
• OUTPUT FREQUENCY LIMIT .....	91
• MOTOR STALL PREVENTION FUNCTION .....	92
• FULL-RANGE AUTOMATIC TORQUE BOOST .....	94
• MULTIFUNCTION CONTACT INPUT FUNCTION SELECTION .....	94
• MULTIFUNCTION PHOTO-COUPLER OUTPUT FUNCTION.....	98
• DC INJECTION BRAKING .....	99
• FREQUENCY/CURRENT METER CALIBRATION.....	100
• OVERTORQUE DETECTION FUNCTION .....	101
• CARRIER FREQUENCY .....	102
• ARBITRARY SPEED DETECTION LEVEL ADJUSTMENT AND SELECTION .....	103
• FREQUENCY JUMP FUNCTION SETTING .....	105
• CONSTANTS EFFECTIVE FOR REDUCTION OF MACHINE VIBRATION OR SHOCK.....	106
• SPEED SEARCH FUNCTION.....	107
• CONTINUOUS OPERATION AT MOMENTARY POWER LOSS.....	109
• AUTOMATIC RESTART FUNCTION AFTER A FAULT.....	112
• ACCEL/DECEL HOLD COMMAND.....	114
2.10 PROTECTIVE FUNCTIONS .....	116
2.11 WARNING AND SELF-DIAGNOSIS FUNCTIONS .....	120

### CAUTION

All the potentiometers of AF-3000 have been adjusted at the factory. Do not change their settings unnecessarily.

Do not make withstand voltage tests on any part of the AF-3000 unit. It is electronic equipment using semiconductors and vulnerable to high voltage.

Make sure to tighten screws on the main circuit and control circuit terminals. Refer to installation instructions for torque values. See par. 1.53 “(5) Wire and terminal screw sizes.”

Handle with care so as not to damage the inverter during transportation.

Do not pick up by the front cover or the unit cover (plastic portion). Use the die-cast portion.


### ADVERTISSEMENT

Des tensions subsistent aux bornes des condensateurs pendant cinq minutes après l'ouverture de circuit d'entrée.

Couper l'alimentation avant d'entreprendre le dépannage du système électrique.

### ATTENTION

Une protection distincte contre les surintensités, la surcharge et la surchauffe de moteur doit être fournie conformément AU CODE CANADIEN DE L'ÉLECTRICITÉ PREMIER PARTIE et LE NATIONAL DE L'ÉLECTRICITE.



### WARNING

Twist wires together before inserting in grounding terminal.

### CAUTION

Separate motor overcurrent, overload and overheating protection is required to be provided in accordance with CANADIAN ELECTRICAL CODE, PART I and NEC.

Use 75°C copper wires only.

Low voltage terminals shall be wired with Class I Wiring.

When mounting units in an enclosure, remove the top, bottom and terminal covers.

### AVERTISSEMENT

Enroulez les fils ensemble avant de les introduire dans la borne.

Des tensions subsistent aux bornes des condensateurs pendant cinq minutes après l'ouverture de circuit d'entrée.

Couper l'alimentation avant d'entreprendre le dépannage du système électrique.

### ATTENTION

Une protection distincte contre les surintensités, la surcharge et la surchauffe de moteur doit être fournie conformément AU CODE CANADIEN DE L'ÉLECTRICITÉ PREMIER PARTIE et LE NATIONAL DE L'ÉLECTRICITE.

The AF-3000 is an ultra-compact, all-digital inverter which provides low noise operation.


Two types are available : 1) with digital operator or 2) with drive status indicating plate (indicating plate).

The digital operator allows maximum utilization of the drive by providing access to the inverter's program constants and operation variables.

The model with the indicating plate provides status and fault codes while preventing unauthorized access to the programming constants. It is also useful for those applications where the programming operator can be moved from one unit to another.

### 1.1 PARTS NAMES OF AF-3000


- With digital operator



- With indicating cover


The indicating cover shown to the right will be mounted in place of the digital operator which is installed in the unit.

INDICATING COVER




# SPECIFICATIONS

## 1.8.2 Dimensions in inches (mm)



Voltage	Ratings			Dimensions						Weight
	HP	kW		H	Hm	W	Wm	D	d	
200-230 3-Phase Input	1/8-1/2	0.1-0.4	in mm	5.91 150	5.43 138	4.13 105	3.66 93	3.94 100	0.20 5.0	2.43 lb 1.1 kg
	1-2	0.75-1.5	in mm	5.91 150	5.43 138	5.51 140	5.04 128	5.47 139	0.20 5.0	4.41 lb 2.0 kg
	3-5	2.2-3.7	in mm	7.87 200	7.32 186	5.51 140	4.96 126	6.69 170	0.22 5.5	7.28 lb 3.3 kg
200-230 1-Phase Input	1/8-1/2	0.1-0.4	in mm	5.91 150	5.43 138	5.51 140	5.04 128	5.47 139	0.20 5.0	4.9 lb 2.2 kg
	1-2	0.75-1.5	in mm	7.87 200	7.32 186	5.51 140	4.96 126	6.69 170	0.22 5.5	6.6 lb 3.0 kg
	3-5	2.2-3.7	in mm	7.87 200	7.28 185	7.48 190	6.89 175	7.48 190	0.24 6.0	11.0 lb 5.0 kg
380-460 3-Phase	1/8-1/2	0.2-0.4	in mm	7.87 200	7.32 186	5.51 140	4.96 126	4.72 120	0.22 5.5	4.41 lb 2.0 kg
	1-2	.75-1.5	in mm	7.87 200	7.32 186	5.51 140	4.96 126	6.69 170	0.22 5.5	6.61 lb 3.0 kg
	3-5	2.2-3.7	in mm	7.87 200	7.28 185	7.48 190	6.89 175	7.48 190	0.24 6.0	10.14 lb 4.6 kg




# DIGITAL OPERATOR

## 2. DIGITAL OPERATOR (OS-9)

The digital operator (OS-9), mounted directly on the inverter, is an AF-3000 exclusive use operation panel which can perform operation, change the control constants and monitor operation status.

### 2.1 DIGITAL OPERATOR MOUNTING/REMOVING

The digital operator can be mounted and removed in the following procedures. It cannot be mounted or removed during current conduction. Be sure to turn off the inverter power supply and mount/remove it after the charge lamp is extinguished. Unless otherwise, it may cause malfunction.





#### How to mount operator

Insert the operator in the direction of the arrow mark until it goes to the end.


#### How to remove operator

(1) Press in the direction of ① and, at the same time, lift it in the direction of ③ to remove the terminal cover.

(2) Lower the lever in the direction of ③ and insert the minus driver in section A. Then lift the operator in the direction of ④ to remove it.










# DIGITAL OPERATOR

## 2.2 DESCRIPTION OF DIGITAL OPERATOR DISPLAY AND OPERATING SECTIONS




\* RUN or STOP lamp changes in accordance with the operations







## 2.3 FUNCTION/CONSTANT SETTING

### 2.3.1 DRIVE Mode and PRGM (Program) Mode

Selection of DRIVE mode or PRGM mode can be performed by using the  key when the inverter is stopped. When function selection or a change of set value is required, switch to the PRGM mode.

- Operation is enabled.

#### DRIVE mode


- An operation can be performed by , ,  or  keys.


- Frequency reference value can be changed during running.

#### PRGM mode


- Program (function selection, constant setting) can be changed. Operation is not enabled.

#### Display Contents of DRIVE Mode and PRGM Mode

- Display contents of the digital operator differ according to selected mode (PRGM/DRIVE).
- The constant group to be displayed is changed each time display selection key  is depressed.
- If a fault occurs, the contents are displayed. Additionally, since the contents of the latest fault are stored, maintenance, inspection or troubleshooting can be performed quickly by checking the contents by the digital operator.








### 2.3.2 Constant Reading and Setting

The AF-3000 has various functions for the optimum operation. The first functions are those basic to drive motors. The second are for basic applications. The third are more advanced application functions. Use it with the set values according to the load conditions or operation conditions of the matching machine. Control constants are read or set by the digital operator. Set constant (No.00) as follows:


- (1) 1st functions (constant Nos.00 to 19) can be set/read :  
No.00 = 1 (Factory setting)
- (2) 1st and 2nd functions (constant Nos.00 to 29) can be set/read :  
No.00 = 2
- (3) 1st, 2nd and 3rd functions (constant Nos.00 to 59) can be set/read :  
No.00 = 3

#### <Typical setting>

- The following shows an example where acceleration time (No.09) is changed from 10 seconds to 5 seconds.
- Other constants can be changed in the same operation.



Note : Check that End is displayed for each constant setting. Constants cannot be changed simultaneously.




### 2.3.3 Precautions on Constant Setting

- Perform constant setting securely.  
Improper setting may cause functions not to operate or protective function to operate.
- Record the constants of which setting has been changed.  
Recording the final setting of constants is effective for maintenance or early troubleshooting. Refer to the Par. 2.8 "FUNCTION/CONSTANT LIST" which has a column for entering setting of constants on page 70.
- Change control constants little by little.  
Do not change the motor control constant setting such as V/f maximum output frequency, etc. rapidly. Change it little by little, checking the motor current or load machine status. Changing setting very rapidly may affect the inverter or machine.

#### • Setting Error



In the following cases, the set value blinks for 3 seconds and the data before changing are returned.

- When a value exceeding the setting range is set
- If the following condition is not satisfied in the multifunction input selection constant setting :  
Multifunction input selection 1 (No. 32)  
Multifunction input selection 2 (No. 33)
- If the following conditions are not satisfied in the V/f constant setting :  
Max. output frequency (No. 02)  $\geq$  Max. voltage frequency (No. 04)  $>$  Intermediate output frequency (No.05)  $\geq$  Min. output frequency (No. 07)  
For the following setting, intermediate output frequency voltage (No. 06) is disregarded :  
Intermediate output frequency = Min. output frequency.  
For details, refer to "V/f CHARACTERISTIC SETTING" on page 84.
- If the following condition is not satisfied in the frequency reference constant setting :  
Set frequency reference (Nos. 13 to 17)  $\leq$  Max. output frequency (No. 02)  $\times$  Output frequency upper limit value (No. 24)  
For details, refer to "V/f CHARACTERISTIC SETTING" on page 84 and "OUTPUT FREQUENCY LIMIT" on page 91.
- If the following condition is not satisfied in the frequency reference upper / lower limit value setting :  
Frequency reference lower limit value (No. 25)  
 $\leq$  Frequency reference upper limit value (No. 24)





## 2.4 DIGITAL OPERATOR OPERATION EXAMPLE

The following shows an example of digital operator operation.



(Cont'd)





## 2.5 CONSTANT INITIALIZATION AND WRITE-IN PROHIBIT

### 2.5.1 Constant Initialization (Operation to return to factory setting)

- Write in 8 to constant (No.00).

[Description]	[Key Operation]	[Digital Operator Display]
• Select PRGM mode.		<code>no-01</code>
• Select constant (No.00).		<code>no-00</code>
• Constant (No.00) data is displayed.		<code>01</code> *
• Change the set value.		<code>08</code>
• Write in the set value. (End is displayed for 1 second.) The data are displayed again after End is displayed.		<code>End</code> <code>01</code> †

\* Differs according to the setting data before changing.

† The display returns to `01` after write-in. This indicates that initialization is executed at writing in the data.


### 2.5.2 Constant Write-in Prohibit (Only constant reading possible)

- The following shows an example where 0 is written in to constant (No.00) [password (No.00) setting/reading and the first functions (constant Nos. 01 to 19) reading enabled].

[Description]	[Key Operation]	[Digital Operator Display]
• Select PRGM mode.		<code>no-01</code>
• Select constant (No.00).		<code>no-00</code>
• Constant (No.00) data is displayed.		<code>01</code> *
• Change the set value.		<code>00</code>
• Write in the set value. (End is displayed for 1 second.) The data are displayed again after End is displayed.		<code>End</code> <code>00</code>

\* Differs according to the setting data before changing.

For details, refer to "PASSWORD SETTING" on page 79.




## 2.6 CORRECTIVE FUNCTION

### 2.6.1 Adjustment of Frequency Setting Value, Output Frequency Bias (No.23) and Gain (No.22)

Any desired value of output frequency for frequency set value (0 to 10V or 4 to 20mA) can be set.

<Example> Adjust so as to obtain 10% speed (6Hz) at frequency setting voltage 0V and 100% speed (60Hz) at 8V.  
[Set constant (No.23)=0.10 and constant (No.22) = 1.23.]

[Description]	[Key Operation]	[Digital Operator Display]
· Select PRGM mode.		no-0!
<Bias> · Select constant (No.23).		no-23
· Data (No.23) are displayed.		0.00
· Change the set value.		0.10 (10%=0.1)
· Write in the set value. (End is displayed for 1 second.) The data are displayed again after End is displayed.		End 0.10



<Gain> · Select constant (No.22).		no-22
· Data (No.22) are displayed.		1.00
· Change the set value.		1.23 *
· Write in the set value. (End is displayed for 1 second.) The data are displayed again after End is displayed.		End 1.23

\*How to calculate gain

$$x = \frac{100 - b}{a} \dots (1) \quad G = \frac{10x + b}{100} \dots (2)$$


x can be obtained by equation (1).

$$x = \frac{100 - 10}{8} = 11.25$$

Then by substituting x obtained in equation (1) for equation (2) to obtain G :

$$G = \frac{10 \times 11.25 + 10}{100} = 1.225 \\ = 1.23$$


- a : Setting voltage at 100% frequency (V)  
In this example, since 100% speed (60Hz) is obtained at 8V, a = 8.
- b : Bias level (%)  
In this example, since 10% speed (6Hz) is obtained at frequency setting voltage 0V, b = 10.
- G : Gain set value  
In this example, it is 1.23.



## 2.6.2 Calibration of Frequency Meter

Calibration of frequency meter or ammeter connected to the inverter can be performed even without providing a calibration resistor.

<Example> When the frequency meter specifications are 3V (1mA) full-scale, 3V full-scale output is used at maximum output frequency [constant (No.02)] operation.  
 [Set constant (No.45) = 0.30.]



## Frequency Meter Calibration


[Description]	[Key Operation]	[Digital Operator Display]
• Select PRGM mode.		no-01
• Select constant (No.45).		no-45
• Data are displayed.		1.00
• Change the set value.		0.30 10 V × 0.3 = 3.0 V*
• Write in the set value. (End is displayed for 1 second.) The data are displayed again after End is displayed.		End 0.30

\* Since analog monitor gain is set to 1.00 prior shipping, 10V is output at maximum output frequency [constant (No.02)] operation.

Note : By data display of constant (No.45) in the program mode, voltage at 100% level according to the constant (No.45) set value is output by the meter calibrating function without any conditions.

(Example) Assuming constant (No.45) = 0.30 :  $10V \times 0.30 = 3V$  is output without any conditions.







## 2.7 MONITOR

Frequency reference value, output frequency, output current and fault contents can be monitored.


### 2.7.1 Typical Monitor Contents and Display (DRIVE Mode)

The monitor item is changed every time the  key is depressed.



### 2.7.2 Monitoring of Fault Contents

· If a fault occurs, the fault contents are displayed with priority over other display items.

Depress the  key or turn on the fault reset input signal to reset the fault.

· Since the latest fault content data are stored in the inverter, even if the power supply is turned off, they can be monitored after the power supply is turned on again.

- (1) Checking fault contents  
The latest data are stored in the constant (No.48). (except UV)
- (2) Clearing fault contents  
The contents are cleared by setting "6" to the constant (No.00).  
Or they are also cleared by constant initialization. [Set constant (No.00)=8 or 9.]  
At this time, other constants are changed to the factory setting values. Therefore, record all of the constant data before initializing constant.
- (3) Faults to be stored  
OC (overcurrent), OV (overvoltage), OH (cooling fin overheat), OL1 (motor overload), OL2 (inverter overload), OL3 (overtorque detection), EF4, EF5 (external fault), CPF05 (AD converter fault).  
For details, refer to Table 1.8 "Fault Display and Contents" on page 35.